

ORDER # D-030-027

Includes 1: 7" & 8" Upright Foam Pads
Includes 2: 10" Upright Foam Pads

hipGRIP® Upright Support Foam Pad Set

SUPPLIES NEEDED: SOAP OR WAX

TO REMOVE:

1. Pull Foam Pads off of the Upright Support.
2. Clean Upright Support with mild soap solution. (NO ADHESIVE IS USED ON UPRIGHT SUPPORTS)
3. LET DRY THOROUGHLY.




FIGURE 1
NOTE: Thick side of pad toward patient

TO REPLACE:

1. Rub SOAP OR WAX on the edges of the Upright Support.
2. Pull NEW FOAM PADS onto the Upright Support, like placing a stocking on a foot, ie; grasp open end and pull over support. (SEE FIGURE 1) THICK PART OF THE PAD MUST BE ON THE SIDE CONTACTING THE PATIENT.
3. Clean any excess wax or soap from exposed area of the support.
4. Apply pressure on both sides of the pad to ensure good conduct between the surface of the support and the pads.

IMPORTANT MESSAGE TO PREVENT SOILING OF POSITIONER PADS

It is recommended that the following precautions are implemented:

Use the **Coversets** to conduct body moisture and prevent skin irritation. (These covers do not protect the foam pads from body fluids or skin preparations) Use an adhesive edged **U-Drape** to protect the **Positioner Pads** from solutions used in skin preparation and body fluids.

Save Replacement Costs

Save replacement costs by taking the above precautions to help avoid contamination of the foam pads from blood, body fluids or skin preparation solutions.

Replacement of Foam Pads is Necessary

Replacing the **Foam Pads** is necessary when they are contaminated with patient body fluids, become hardened or loose their resilience after extensive repeated use, or are damaged in any way that compromises the intended use.



www.sunmedica.com
P 1.800.995.8715 | F 530.229.9457
1661 Zachy Way, Redding, CA 96003

*For more information or to re-order,
you can visit www.sunmedica.com or give us a call
and we will be happy to assist you!*